

# UB



---

## INSTRUCTIONS AND MAINTENANCE MANUAL

---



# INSTRUCTIONS AND MAINTENANCE MANUAL

## ASSEMBLY

### APPLICATION OF EUROPEAN DIRECTIVES

See document of European Directives applicable to **CMO Valves**.



The **UB** valve complies with the Directive on Equipment and Protective Systems for Use in Explosive Atmospheres. In these cases the logo will appear on the identification label. This label shows the exact classification of the zone in which the valve can be used. The user is responsible for its use in any other zone.

### HANDLING

When handling the equipment please pay special attention to the following points:

- **SAFETY WARNING:** Before handling the valve, check that the crane to be used is capable of bearing its weight.
- To prevent damage, especially to the anticorrosive protection, it is recommended to use soft straps to lift the **CMO Valves**. These straps must be fitted around the top of body.
- Do not lift the valve or hold it by the actuator. Lifting the valve by the actuator can lead to operating problems as it is not designed to withstand the valve's weight.
- Do not lift the valve by holding it in the flow passage area. The valve's seal is located in this area. If the valve is held and lifted by this area it can damage the surface and the O-ring seal and lead to leakage problems whilst the valve is operating.
- Packing in wooden boxes: If the equipment is packed in wooden boxes, these must be provided with clearly marked holding areas where the slings will be placed when securing them. In the event that two or more valves are packed together, separation and securing elements must be provided between them to prevent possible movements, knocks and friction during transport. When storing two or more valves in the same box you must ensure they are correctly supported to prevent deformations. In the case of dispatches by sea we recommend the use of vacuum bags inside the boxes to protect the equipment from contact with sea water.
- Pay special attention to maintaining the correct levelling of the valves during loading and unloading as well as during transport to prevent deformations in the equipment. For this purpose we recommend the use of mounts or trestles.



Fig. 1

### INSTALLATION

In order to avoid personal harm and other types of damage (to the facilities, the valve, etc.) please follow these instructions:

- The staff responsible for the installation or operation of the equipment must be qualified and trained.
- Use suitable Personal Protective Equipment (PPE) (gloves, safety boots, goggles, etc).
- Shut off all lines that affect the valve and put up a warning sign to inform about the work being performed.
- Completely isolate the valve from the whole process. Depressurise the process.
- Drain all the line fluid through the valve.
- Use hand tools not electric tools during the installation and maintenance, in according to current regulations




Before installation, inspect the valve to ensure no damage has occurred during transport or storage. Make sure that the inside of the valve body and, in particular, the seal area are clean. Inspect the installation's pipes and the flanges to make sure they are clean.

## ADVANTAGE

### ASPECTS TO BE CONSIDERED DURING ASSEMBLY


The **UB valve** is bidirectional, meaning the direction of the fluid is not important, since it works correctly in both directions. Special care must be taken to respect the correct distance between the flanges and ensure they are correctly aligned and parallel (fig. 2).

The incorrect position or installation of the flanges can cause deformations on the valve's body and this could lead to operating problems.



It is very important to make sure that the valve is correctly aligned and parallel to the flanges to prevent leakages and avoid deformations. Ensure the valve is assembled in open position.

The screws in the tapped blind holes will have a maximum depth P (fig. 3) and will never reach the bottom of the hole.




- The equipment must be firmly installed in the duct. It will be joined to the duct with a screw joint.
- The screws and nuts to be fitted must also be suitable for the operating conditions and their measurements must be in accordance with the approved plans. The screws and nuts must be fitted diametrically.
- The torque to apply to the fastening screws and nuts must be correct according to the applicable standard; we recommend the initial assembly be carried out with a low tightening torque and after all the screws are in place, the final torque applied.
- As regards scaffolding, ladders and other auxiliary elements to be used during the assembly, follow the safety recommendations indicated in this dossier.
- Once the equipment has been assembled, make sure that there are no elements, whether interior or exterior, which can interfere with the movement of the knife gate.
- Make the relevant connections (electrical, pneumatic, hydraulic) in the equipment's actuator system following the instructions and wiring diagrams supplied with it.
- The operation of the equipment must be coordinated with the site's control and safety staff and no modifications are permitted in the equipment's external indication elements (limit switches, positioners, etc.).
- When operating the equipment, follow the safety recommendations indicated in this dossier.

## ASSEMBLY POSITIONS (horizontal pipe)

In horizontal pipes it is recommended that **CMO Valves** valves be assembled in vertical position, although other assembly positions are also possible.

**Position number 1:** This is the most advisable position.



**Position number 8:** The valve can be installed in this position but you are advised to contact **CMO Valves** if this is necessary.

**Positions 2, 3, 6 and 7:** For large valves (over DN300), the maximum installation angle with the vertical is 30°. For smaller sizes the angle can be increased up to 90° (positions 4 and 5).

When it is necessary to install large valves in any of these positions, it is recommended to consult **CMO Valves**, as in these cases, due to the weight of the actuator, a suitable support must be made to prevent deformations and operating problems in the valves.

**Positions 4 and 5:** For smaller sized valves, the valves can be installed in these positions. To install larger valves (over DN300) in any of these positions, please contact **CMO Valves**.

In these cases, due to the weight of the actuator, a suitable support must be made to prevent deformations and operating problems in the valves.

## ASSEMBLY POSITIONS (vertical/leaning pipe)

The valves can be assembled in all positions; however, recommendations do exist for some of them.

**Positions 1, 2 and 3:** In these positions, it is recommended to make a suitable support, since, due to the weight of the actuator, deformations may arise and this can lead to operating problems in the valve.

Once the valve has been installed, check that all the screws and nuts have been correctly tightened and that the whole valve action system has been correctly adjusted (electrical connections, pneumatic connections, instruments, etc).

All **CMO** valves are tested on site, although it is possible that the stuffing box screws (in valves from DN50 to DN600) or the packing nuts (in valves over DN600) may come loose during handling and need to be retightened.

Once the valve is installed in the pipe and has been pressurised, it is very important to check whether there is any leakage in the stuffing box area (upper part of the body in valves from DN50 to DN600) or the packing area (in valves over DN600).

In the event of a leakage, retighten the packing gland nuts or stuffing box screws until the leakage stops, ensuring that there is no contact between the packing gland and the through conduit.




Fig. 5

Once the valve is installed in place, check that the flanges and electrical and pneumatic connections are secure. If the valve has electrical accessories or you are in an ATEX zone, earth connections must be made before operating it.



If you are in an **ATEX** zone, check the continuity between the valve and the pipe (**EN 12266-2**, annex B, points B.2.2.2. Ind B.2.3.1.). Check the pipeline's earth connection and the conductivity between the outlet and inlet pipelines.

## ACTUATOR

### HANDWHEEL

To operate the valve: Turn the handwheel clockwise to close or anticlockwise to open.

### CHAINWHEEL

To operate the valve pull one of the chain's vertical drops, taking into account that sealing is carried out when the chainwheel turns clockwise.

### LEVER

First loosen the position locking clamp located on the yoke. Once it is unlocked, raise the lever to open it or lower to close it. To complete the operation lock the lever again.

### GEAR-BOX

To operate the valve: Turn the handwheel clockwise to close or anticlockwise to open.

### PNEUMATIC (double and single acting)

The pneumatic actuators are designed to be connected to a 6 bar pneumatic network, although these cylinders support up to 10 bar. The pressurised air used for the pneumatic actuator must be correctly filtered and lubricated. This type of actuator does not require any adjustment, due to the fact that the pneumatic cylinder is designed for the exact stroke required by the valve.

### HYDRAULIC

The hydraulic actuators are designed to work at a standard pressure of 135 bar. This type of actuator does not require any adjustment, due to the fact that the hydraulic cylinder is designed for the exact stroke required by the valve.

### MOTORISED

If the valve incorporates a motorised actuator it will be accompanied with the electric actuator supplier's instructions.



H/A = RISING STEM  
H/NA = NON-RISING STEM




Fig. 6

## MAINTENANCE

**CMO Valves** will not be liable if the valves suffer any damage due to improper handling or without proper authorisation. The valves must not be modified except under express authorisation from **CMO Valves**.

In order to avoid personal or material damage when performing the maintenance tasks, it is recommended to follow these instructions:



- The staff responsible for the maintenance or operation of the equipment must be qualified and trained.
- Use suitable Personal Protective Equipment (PPE) (gloves, safety boots, goggles, etc).
- Shut off all lines that affect the valve and put up a warning sign to inform about the work being performed.
- Completely isolate the valve from the whole process. Depressurise the process.
- Drain all the line fluid through the valve.
- Use hand tools not electric tools during the installation and maintenance, in according to current regulations.

The only maintenance required in this type of valves is to change the seat's rubber seal (located between the two body halves) and the stuffing box seal (in valves from DN50 to DN600) or gasket (valves over DN600). It is recommended to regularly check the seal every 6 months, however its working life will depend on the valve's working conditions, such as: pressure, temperature, number of operations, type of fluid and others.



In an ATEX zone, electrostatic charges may be present inside the valve, which can cause a risk of explosion. The user will be responsible for carrying out the appropriate actions in order to minimise the risks.

- The maintenance staff must be informed about the risks of explosion and ATEX training is recommended.
- If the fluid transported constitutes an internal explosive atmosphere, the user must regularly check the installation's correct seal-tightness.
- Regularly clean the valve to prevent accumulation of dust.
- Assembly is not permitted at the end of the line.
- Avoid re-painting the products supplied.

## LUBRICATION



We recommend greasing the stem 2 times per year, applying grease over the entire length of the stem.

After the maintenance and in an ATEX zone, you must check the electrical continuity between the pipe and the rest of the valve's components, such as the body, through conduit, stem, etc. (EN 12266-2 Standard, annex B, points B.2.2.2. and B.2.3.1.).

## IMPORTANT SAFETY ASPECTS

- In order to work under ideal safety conditions, the magnetic and electrical elements must be in idle mode and the air tanks depressurised. The electrical control cabinets must also be out of service. The maintenance staff must be up to date with the safety regulations and work can only start under orders from the site's safety staff.
- The safety areas must be clearly marked and you must avoid placing auxiliary equipment (ladders, scaffolding, etc.) on levers or moving parts which may lead to the movement of the knife gate.
- In equipment with spring return actuators, the knife gate valve must be mechanically locked and only unlocked when the actuator is pressurised.
- In equipment with electrical actuator, it is recommended to disconnect it from the mains in order to access the moving parts without any risk.
- Due to its great importance, you must check that the valve shaft has no load before disassembling the actuator system.

Taking into account the recommendations indicated, below we indicate the maintenance operations carried out in this type of equipment:

## REPLACING THE SEALING JOINT

1. Make sure there is absolutely no pressure and fluid in the facility.
2. Remove the valve from the pipeline.
3. Remove the actuator, the through conduit (2) and the protection devices (when fitted) from the valve, leaving just the body.
4. Once the body has been isolated, release all the screws which secure the two halves of the body (1).
5. Separate the two halves of the body (1) and remove the seal joint (5). If the body is stainless steel, take care not to lose the slides (6) fitted on the inside.
6. Clean the inside surfaces of the body, in particular the seal joint housing.
7. Position a new compression seal (5) of the same size in the same location as the previous one.
8. Reassemble the two body halves (1) and secure by screwing.
9. The valve assembly will be performed in exactly the opposite way to the disassembly.




Fig. 7

**\*Nota:** During the assembly of the new sealing joint it is recommended to apply "Vaseline" to the seal to facilitate the assembly process and the correct operation of the valve (do not use oil or grease); table 2 below shows details of the Vaseline used by **CMO Valves**.

PETROLEUM JELLY		
Saybolt colour	ASTM D-156	15
Melting point (°C)	ASTM D-127	60
Viscosity at 100°C	ASTM D-445	5
Penetration 25°C mm./10	ASTM D-937	165
Silicone content	None	
Pharmacopeia BP	OK	

Table. 1

## REPLACING THE GLAND

As mentioned above, valves DN50 to DN600 have a stuffing box seal rather than a gasket. Valves over DN600 do have the traditional gasket system.

## REPLACING THE STUFFING BOX SEAL (VALVES DN50 - DN600)

1. Make sure there is absolutely no pressure and fluid in the facility.
2. Remove the valve from the pipeline.
3. Remove the actuator, the through conduit (2) and the protection devices (when fitted) from the valve, leaving just the body.
4. Once the body has been isolated, release all the screws which secure the two halves of the body.
5. Separate the two halves of the body (1) and remove the seal joint (5) and then the stuffing box seals (4) of each body half. If the body is stainless steel, take care not to lose the slides (6) fitted on the inside.
6. Clean the inside surfaces of the body (1), in particular the seal joint housing and the stuffing box seals.
7. Position new stuffing box seals (4) of the same size in the same location as the previous ones.
8. Reassemble the two body halves (1) and secure by screwing
9. The valve assembly will be performed in exactly the opposite way to the disassembly.




Fig. 8

## REPLACING THE GLAND (VALVES OVER DN600)

1. Make sure there is absolutely no pressure and fluid in the facility.
2. Place the valve in open position.
3. If the valve has safety protections, remove them.
4. Loosen the screws that connect the stem or spindle to the through conduit.
5. Loosen the connection between the support plates (7) and the body (1), and remove the actuator.
6. Release and remove the packing gland (4).
7. Remove the gasket (3) using a pointed tool, taking care not to damage the surface of the through conduit (2).
8. Carefully clean the gasket, making sure there are no residues anywhere so the new gasket strips fit correctly.
9. Insert the new gasket (3). As standard, **CMO Valves** valve packing comprises several gasket lines and one rubber joint line in the middle.
10. Place the packing gland (4) in its original position, making sure it does not touch the through conduit (2), carefully tighten all the screws crosswise and make sure the same distance is left between the through conduit (2) and the packing gland (4) on both sides.
11. Screw down the support plates (7) and the stem (9), in reverse order to that described in steps 4 and 5.
12. If the valve has safety protections, return them.
13. Perform several manoeuvres with no load, checking the correct operation of the valve and ensuring the packing gland (4) is correctly aligned.
14. Pressurise the valve in the line and tighten the packing gland (4) crosswise, enough to prevent leakages to the atmosphere.




Fig. 9



## MAINTENANCE OF THE PNEUMATIC ACTUATOR

The pneumatic cylinders in our valves are manufactured and assembled at our premises. The maintenance of these cylinders is simple, if your need to replace any elements and you have any questions please consult **CMO Valves**. Below is an exploded diagram of the pneumatic actuator (fig. 10) and a list of the cylinder's components (table 2). The top cover and the support cover are usually made of aluminium, but from pneumatic cylinders greater than Ø200 mm, they are made of cast ductile iron.

The maintenance kit normally includes: The socket and its joints and the scraper, and if the customer wishes the piston is also supplied. Below we show the steps to follow to replace these parts.

1. Position the valve in closed position and shut off the pneumatic circuit pressure.
2. Loosen the cylinder air input connections.
3. Release and remove the cylinder cap (5), the cylinder tube (4) and the tie rods (16).
4. Loosen the nut (14) which connects the piston (3) and the rod (1), remove the parts. Disassemble the cir-clip (10) and remove socket (7) with its joints (8 & 9).
5. Release and remove the cylinder head (2), in order to remove the scraper (6).
6. Replace the damaged parts with new ones and assemble the actuator in the opposite order to that described for the disassembly.




Fig. 10

PNEUMATIC ACTUATOR		
POS.	DESCRIPTION	MATERIAL
1	STEM	AISI-304
2	COVER SUPPORT	ALUMINIUM
3	PISTON	S275JR + EPDM
4	CASING	ALUMINIUM
5	UPPER COVER	ALUMINIUM
6	SCRAPER	NITRILE
7	SOCKET	PA6
8	EXTERIOR O-RING	NITRILE
9	INTERIOR O-RING	NITRILE
10	CIR-CLIP	STEEL
11	WASHER	ST ZINC
12	O-RING	NITRILE
13	WASHER	ST ZINC
14	SELF-LOCKING NUT	5.6 ZINC
15	O-RING	NITRILE
16	TIES	F-114 ZINC
17	WASHER	ST ZINC
18	NUT	5.6 ZINC
19	SCREW	5.6 ZINC
20	WASHER	ST ZINC
21	NUT	5.6 ZINC
22	SCREW	A-2
23	PROTECTION	S275JR

Table. 2

## STORAGE

To ensure the valve is in optimum conditions of use after long periods of storage, it should be stored in a well-ventilated place at temperatures below 30°C.

It is not advisable, but if it is stored outside, the valve must be covered to protect it from heat and direct sunlight, with good ventilation to prevent humidity. The following aspects must be considered for storage purposes:

- The storage place must be dry and under cover.
- It is not recommended to store the equipment outdoors with direct exposure to adverse weather conditions, such as rain, wind, etc, even when the equipment is packaged.
- This recommendation is even more important in areas with high humidity and saline environments. Wind can carry dust and particles which can come into contact with the valve's moving parts and this can lead to operating difficulties. The actuator system can also be damaged due to the introduction of particles in the different elements.
- The equipment must be stored on a flat surface to avoid deformations.
- If the equipment is stored without suitable packaging it is important to keep the valve's moving parts lubricated, for this reason it is recommended to carry out regular checks and lubrication.
- Likewise, if there are any machined surfaces without surface protection it is important for some form of protection to be applied to prevent the appearance of corrosion.

## COMPONENTS LIST (DN50-DN600)




Fig. 11

HANDWHEEL DRIVE	
POS.	DESCRIPTION
1	BODY
2	THROUGH CONDUIT
3	SEAL RIM
4	STUFFING BOX SEAL
5	SEALING JOINT
6	SLIDES
7	SUPPORT PLATES
8	STEM
9	YOKE
10	STEM NUT
11	CHECK NUT
12	HANDWHEEL
13	NUT
14	HOOD
15	TOP CAP

Table. 3

## COMPONENTS LIST (Manual valves over DN600)




Fig. 12

HANDWHEEL DRIVE	
POS.	DESCRIPTION
1	BODY
2	THROUGH CONDUIT
3	GASKET
4	PACKING GLAND
5	SEALING JOINT
6	SUPPORT PLATES
7	STEM
8	YOKE
9	GEARED MOTOR
10	HOOD
11	TOP CAP
12	HANDWHEEL

Table. 4



[www.cmovalves.com](http://www.cmovalves.com)



**CMO**VALVES

QMS CERTIFIED BY LRQA  
Approval number ISO9001 0035593

**CMO VALVES**  
**HEADQUARTERS MAIN**  
**OFFICES & FACTORY**

Amategi Aldea, 142  
20400 Tolosa  
Gipuzkoa (Spain)

Tel.: (+34) 943 67 33 99

[cmo@cmovalves.com](mailto:cmo@cmovalves.com)  
[www.cmovalves.com](http://www.cmovalves.com)

**CMO VALVES**  
**MADRID**

C/ Rumania, 5 - D5 (P.E. Inbisa)  
28802 Alcalá de Henares  
Madrid (Spain)

Tel.: (+34) 91 877 11 80

[cmomadrid@cmovalves.com](mailto:cmomadrid@cmovalves.com)  
[www.cmovalves.com](http://www.cmovalves.com)

**CMO VALVES**  
**FRANCE**

5 chemin de la Brocardière  
F-69570 DARDILLY  
France

Tel.: (+33) 4 72 18 94 44

[cmofrance@cmovalves.com](mailto:cmofrance@cmovalves.com)  
[www.cmovalves.com](http://www.cmovalves.com)